



Error type		Code display	Display area	Remarks
Refrigerator Sensor Error	R-compartment	E1	R-compartment 7-SEG	T<-50°C, T>50°C
	F-compartment	E2	F-compartment 7-SEG	T<-50°C, T>50°C
Ice Temperature Compartment	M-compartment	E3	M-compartment 7-SEG	T<-50°C, T>50°C
Defrosting Sensor Error	R-EVA	E4	R-compartment -SEG	T<-50°C, T>50°C
	F-EVA	E5	F-compartment -SEG	T<-50°C, T>50°C
Communication Error		E6	R-compartment 7-SEG	-
Ambient Sensor Error	-	E7	R-compartment 7-SEG	T<-50°C, T>50°C
F-compartment High Temperature Alarm	F-compartment	E9	F-compartment 7-SEG	-
Ice_make_Initial Error	F-compartment	E0	F-compartment 7-SEG	-